ELEKTRO PARTNER

BULLETIN

Side 1 av 7

-

BILMERKE / MODELL:

LØSNING:

ÅRGANG: Alle MOTORKODE: Alle

EMNE / SYMPTOM / FEILKODE:

TEXA - myTEXA Opretting av flere brukere til 2-faktor pålogging

Workshop manager: Tester ansvarlig (workshop manager) skal logge inn på hjemmesiden med sin egen myTEXA ID og kode. www.mytexa.com myTEXA Language - Login TEXA Login **myTEXA** Registering is quick and easy and gives you access to everything that regards the world of "TEXA". myTEXA is the portal that allows TEXA customers to create a personal profile, enabling them to access all specially dedicated services even outside the workshop. ENTER HELP First of all, via a link within this portal, the user can access the dedicated area of DOWNLOAD MANAGER, the new application specifically developed to make procedures for downloading the diagnostic software easier, quicker and even more protected Furthermore, it will be possible to subscribe to the newsletter and receive all the latest news, regarding the comp Sign up relative updates and upgrades, as well as the TEXAEDU calendar of their courses, and much more Recover e-mai Sign in Sign in with your email address @elektropartner.dk got your pa word? -







ELEKTRO PARTNER

LØSNING FORTSETTER:

<complex-block></complex-block>	Trykk "Click here to access" (pil).	
<complex-block> Indexted where whe</complex-block>	TEXA MY EQUIPMENT	Language - Logout Texa.app download manager profile management sgw management
<complex-block></complex-block>	. New profile page: here you can edit and confirm your person	nal data and workshop data! Click here to access.
<image/>	PURCHASED EQUIPMENT	
Seid number: N: Numbrage for Point		
Addression caller CULRENCE TEXA	Serial number: TNS NanoDiag for PC	Serial number: DN NAVIGATOR NANO S
EQUIPMENT DETAIL Company profile Image: Company profile <	Activation date: 23/01/2015	Activation date: 15/11/2022
Vælg "Profile management" (pil). INTEX Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile annjelon Profile an	EQUIPMENT DETAIL	
myTEXA Linguage * Logout Profile completion Profile completion Company profile Compan	Vælg "Profile management" (pil).	
ektropartner.dk Profile completion	TEXA	Language + Logout
ektropantner dk Potile completion Personal profile Personal profile Last name Last name Last name Last opping in the validation Company profile validation Change, nassword Company profile validation Change, nassword Change, nassword Change, nassword Company profile validation Change, nassword Change, nassword Company profile validation Change, nassword Company profile validation Change, nassword Change, nassword Change, nassword Change, nassword	_	PROFILE MANAGEMENT WORKSHOP
Profile completion Last name Personal profile	ektropartner dk	Personal profile
Personal profile > E-mail Company profile validation > Change password > Change password >	Profile completion	Last name
Company profile Image: Company profile validation Company profile validation Date of birth Change, password Vour identity has been confirmed!	✓ Personal profile >	E-mail
Change password Change password Disassociate user	Company profile	mexuopautiei ok Date of birth
Christige (asservice)		
MFArtset	Change hassword Disassociate user MEAresst	Vour identity has been contirmed!
Go to next step >		Go to next step >
Trykk:	Trykk:	
1. Invite employee	1. Invite employee	
2. Inntast medarbeiderens e-postsdresse		
3. Trykk send	3. Trykk send	

TEX	CA MYTEXA		Language + Logout
Empl +	loyee profiles Invite employee t	PROFILE MANAGEMENT COORGHOP	
Last	name 1 First na	ne E-mail	Entry date
	2	Invite employee × E-mail elektropanner.dk	
		ELEKTRO	FORTSETTELSE



ELEKTRO PARTNER

-

BULLETIN

LØSNING FORTSETTER:

Medarbeider:

Medarbeideren som skal ha mulighet for 2-faktor godkjennelse vil nå motta en e-post med en invitasjonskode.

- 1. Noter invitasjonskoden
- 2. Trykk "complete the registration"

TEXA - Invitation code		(;;;) ←	Svar	≪ Svar til alle	→ Videresend	6	
N noreply@texa.com					ma	15-05-20	23 10:05
(i) Hvis der er problemer med visningen af meddelelsen, k	an du klikke her for at få vist den i en webbrowser.						
🛐 Oversæt meddelelsen til: Dansk 🛛 Oversæt aldrig f	ra: Engelsk Oversættelsesindstillinger						
	Complete the registration process to access the TEXA services	5					
	Dear customer, to complete the registration process click on the following link, enter you the invitation code indicated below.	ir data and	t				
	COMPLETE THE REGISTRATION						
	INVITATION CODE: ABCDEF						
	Good luck with your work						
	TEXA						
	If you did not request to subsribe to the TEXA services, ignore this email.						
	This message was sent from an electronic mail address that is not verified. Do not respond to the message.						

Utfyll formularen og inntast en valgfri kode (skal inneholde store og små bokstaver og 1 spesialtegn). Vi anbefaler å anvende en kode som er lett å huske siden det er den samme koden som skal brukes hver gang 2-faktorgodkjennelsen skal gjennomføres fremover. Inntast invitasjonskoden fra e-posten i det nederste feltet.

	Cancel	
	@elektropartner.dk	
	New Password	
	Confirm New Password	
	Given Name	
the second s	Surname	
	Invitation Code	
	Privacy Policy The User is invited to read and accept TEXA Privacy Policy provided in compliance with EU Regulation 2016/679.	
	* I have read and accept the Privacy Policy Circuite Circuite	





ELEKTRO PARTNER

BULLETIN

Side 4 av 7

LØSNING FORTSETTER:

Registrering av en ekstra bruker er nå gjennomført.



Workshop manager:

Trykk Update (pil) for å bekrefte at konfigureringen er fullført.



Medarbeider:

Åpne TEXA diagnosetesteren.

- 1. Trykk på personen i høyre hjørne
- 2. Eller logg inn som en annen bruker

TEXA		→ û & <mark>◎</mark> ^{Nenu}		IDC5 v.76.0.1 X
Diag	Inose			
	Q	Ĩ	io adas	Authenticator
	Diagnose	Mileage and VIN check	Videokamera/radar kalibrering	Sørg for at du bruger den tilsvarende bruger som påkrævet af producenterne af sikkerhedsmæssige årsager.
	Ô	•	() WEB	Fjern
Pro tra	ogrammering af ansporttilstand	Special Functions	Løste fejl	R MASTER USER
Link	s og andre funktio	oner		Log ind som en anden bruger 2 Brugerkonfigurationen i myTFXA
	(DU) Ø			





ELEKTRO PARTNER

-

LØSNING FORTSETTER:



Logg inn via faktorgodkjennelse på smarttelefon.

Hvis man ikke allerede har en "Authenticator App" fra enten Google eller Microsoft, så kan de hentes i App-store eller Google-store.

I dette eksempelet anvendes Authenticator-appen fra Microsoft.

- 1. Google Authenticator
- 2. Microsoft Authenticator
- 3. Når programmet er installert på en Smarttelefon skal man velge bekreftede ID'er
- 4. Trykk på Skann QR-kode









ELEKTRO PARTNER BULLETIN

-

LØSNING FORTSETTER:

QR-koden skannes fra TEXA med Authenticator-appen.



Prosedyren nedenfor skal fremover gjennomføres hver gang man logger inn på myTEXA på TEXA-diagnosetesteren.

Authenticator-App'en vil nå vise en rullende kode som skifter for hvert 30 sekund. Inntast koden i TEXA og logg heretter inn.







ELEKTRO PARTNER

BULLETIN

LØSNING FORTSETTER:

Det bekreftes nå at konfigurasjonen er korrekt gjennomført.



Du er nå logget inn.

TI		→ 企 ぐ 📀 ^{Venu} 〉						IDC5 v.76.	
	Diagnose							VCI forbindelse:	C Logout
l	Q			ନ୍ଦୁ	<u><u></u>*↓</u> -+	@≵		(!) TPMS	
	Diagnose			Elbiler					
l		9	(?) WEB	PDF XML	EOBD TEST	/!\			
				Report repository					
Links og andre funktioner									
				my TEXA					
Se	også bulle	tin nr. 963	34.						

