ELEKTRO PARTNER

BULLETIN

Page 1 of 9

č



MAKE / MODEL:

YEAR: All ENGINE CODE:

SUBJECT / SYMPTOM / TROUBLE CODE:

TEXA - myTEXA Creation of multiple users to 2-factor login

SOLUTION: Workshop manager: The workshop manager must log in to the website with his own myTEXA ID and code. www.mytexa.com Login TEX/ myTEXA Login **myTEXA** gistering is quick and easy and gives you access to arything that regards the world of "TEXA". Regist myTEXA is the portal that allows TEXA customers to create a personal profile, enabling them to access all specially dedicated services even outside the workshop. ENTER HELP First of all, via a link within this portal, the user can access the dedicated area of DOWNLOAD MANAGER, the new application specifically developed to make procedures for downloading the diagnostic software easier, quicker and even more protected. Furthermore, it will be possible to subscribe to the newsletter and receive all the latest news, regarding the company, its p relative updates and upgrades, as well as the TEXAEDU calendar of their courses, and much more. Sign up Sign in Sign in with your email address @elektropartner.dk rgot your pa word? ٩ -----調調調 -- 22







ELEKTRO PARTNER BULLETIN

SOLUTION CONTINUED:

Press "Click here to access" (arrow).
TEXA myTEXA Languago - Lagoat
MY EQUIPMENT TEXA APP DOWNLOAD MANAGER PROFILE MANAGEMENT SGW MANAGEMENT
Rew profile page: here you can edit and confirm your personal data and workshop data! Click here to access.
PURCHASED EQUIPMENT
Serial number: TVS Serial number: DY
NanoDiag for PC NAVIGATOR NANO S Activation date: Activation date:
23/01/2015 15/11/2022
EQUIPMENT DETAIL
Select "Profile management" (arrow).
TEXA Language ~ Logout
PROFILE MANAGEMENT WORKSHOP
Personal profile First name
Las name
Personal profile E-mail Mektropartnet.dk
Company profile validation
Change password Vour identity has been confirmed!
MFA reset Go to next step >
Press:
1. Invite employee
2 Enter the employee's empile

3. Press submit

TEXA	A MYTEXA			
		PROFILE MANAGEMENT WORKSHOP		
Emplo	byee profiles			
+ in	nvite employee 😤 Invitation history 🖉 Update			
Last na	name	e E-mail	Entry date	
¢	*			
		Invite employee	×	
		E-mail		
	2	elektropartner.dk		
		3 cr Send	Cancel	
		NGHTS REAL		
		entre and a second		



ELEKTRO PARTNER BULLETIN

č

SOLUTION CONTINUED:

Employee:

The employee who needs to have the option of 2-factor authentication will now receive an email with an invitation code.

- 1. Make a note of the invitation code
- 2. Press "complete the registration"

TEXA - Invitation code						
N noreply@texa.com			← Svar	≪ Svar til alle	→ Videresend	5-05-2023 10:05
i) Hvis der er problemer med visningen af meddelelsen, k	an du klikke her for at få vist den i en webbrowser.					
Source of the second se	a: Engelsk Oversættelsesindstillinger					
	Complete the registration process to access the TEXA services	l)				
	Dear customer, to complete the registration process click on the following link, enter you the invitation code indicated below.	ur data a	Ind			
	COMPLETE THE REGISTRATION					
	INVITATION CODE: ABCDEF					
	Good luck with your work					
	TEXA					
	If you did not request to subsribe to the TEXA services, ignore this email.					
	This message was sent from an electronic mail address that is not verified. Do not respond to the message.					

Fill in the form and enter an optional code (must contain capital and small letters as well as 1 special character).

We recommend to use a code that can easily be remembered, as the same code must be used each time the 2-factor authentication is to be implemented in the future. Enter the invitation code from the email in the lower space.

	Cancel		
	@elektropartner.dk		
	New Password		
	Confirm New Password		
	Given Name		
	Surname		
and the second se	Invitation Code		
	Privacy Policy The User is invited to read and accept TEXA Privacy Policy provided in compliance with EU Regulation 2016/679.		
	* I have read and accept the Privacy Policy Create Create		





ELEKTRO PARTNER

BULLETIN

SOLUTION CONTINUED:

The registration of an additional user is now complete.



The user must now complete a Security clearance/validation. The Workshop manager must return to "Profile management". Press the below space "Request available".

TEXA MYTE	XA			Language +	Logout
			PROFILE MANAGEMENT WORKSHOP		
		New profile page: here you can e	dit and confirm your personal data and workshop data! <u>Click here</u>	to access	×
Employee profile	s				
+ Invite employe	e ž≘ Invitation history	2 Update			
Last name	First name	E-mail	Entry date	Identity check status	
			15/05/2023, 13:52	Request available	
« 1 »				- Siles	
	ta ta tha id.	antitus abaals"			

Press "Invite to the identity check". Then press Yes.

TEXA						rungmaga	
_			PROFILE MANAGEMEN	WORKSHOP			
		Lew profile page: her	e you can edit and confirm your pers	onal data and workshop datal <u>Click here t</u>		×	
mployee profiles							
+ Invite employee	¥Ξ Invitation history	2 Update					
Last name	First name	E-mail		Entry date	Identity check	k status	
		ktrop	artner.dk	15/05/2023, 13:52		lable	
< <u>1</u> >		Emplo	yee details Last name	×		Employee details	×
			First name			Confirm	×
			E-mail			Are you sure you want to invite the employe check process?	e to start the identity
			Request available				✓ Yes 🚫 No
			Invite to the identity check	V MFA réset		E Invite to the identity check	MFA reset 💼 Delete
		000		× Close			× Close





Page 4 of 9

ě



Here you can see that the procedure has been marked as complete.

respond to the message.

TEXA MYTEXA				Language - Logo							
		PROFILE M	ANAGEMENT WORKSHOP								
New profile page: here you can edit and confirm your personal data and workshop data! Click here to access											
Employee profiles											
+ Invite employee	ž≘ Invitation history	2 Update									
Last name	First name	E-mail	Entry date	Identity check status							
		elektropartner.dk	15/05/2023, 13:52	Procedure complete							
« 1 »				CLETTED THE							
				Contraction of the second s							
			L RIGHTS RESER								





ELEKTRO PARTNER BULLETIN

Page 6 of 9

č

SOLUTION CONTINUED:

Employee:

Open TEXA diagnostic tool.

- Tap the person in the right corner
- Log in as a different user

TEXA	←	🔿 ଜ ኖ 📀			IDC5 v.76.0.1 📯 🗙
	60-01 ☆	Menu	2	VCI 6	forbinder
Diag	<u>Anose</u>		E Adas	Authenticator) Is
	Diagnose	Mileage and VIN check	Videokamera/radar kalibrering	Sørg for at du bruger den tilsvarende bruger som påkrævet af producenterne af sikkerhedsmæssige årsager.	is
	Ô	•	(?) WEB	Fjern MASTER USER Fjern Fjern Fjern Fjern	
Pro tr	ogrammering af ansporttilstand	Special Functions	Løste fejl	R MASTER USER log ind som	
Link	s og andre funkti	oner		i)uni	
	(D) Ø			Log ind som en anden bruger 2 Brugerkonfigurationen i myTEXA	

Use email and password to log in.

	→ ⋒ ீ 📀	port				IDC5 v.76.0.1 8 ×
Diagnose		¥⊚ Adas	Authentica	din konto	× × ØØ	VCI forbindelse: SMART
Diagnose	Mileage and VIN check	Videokamera/radar kalibrering ? WEB	Sørg	Log på Log på med din e-mailadresse	e af ring af sprog	TPMS
Programmering af transporttilstand Links og andre funkti	Special Functions	Løste fejl	Re	Har du glemt din adgangskodež Log på	n Anders	
(DU æ					myTEXA	





ELEKTRO PARTNER BULLETIN

Page 7 of 9

SOLUTION CONTINUED:

Log in via 2-factor authentication on smartphone.

If you do not already have an "Authenticator App" from either Google or Microsoft, they can be downloaded from the App store or Google store.

This example uses the Authenticator App from Microsoft.

- 1. Google Authenticator
- 2. Microsoft Authenticator
- 3. Once the application is installed on the Smartphone, one must select verified IDs
- 4. Press Scan QR Code













TEXA

ELEKTRO PARTNER BULLETIN

-

SOLUTION CONTINUED: The QR code is scanned from TEXA with the Authenticator App. IDC5 v.76.0.0 X 🥿 🔶 🔶 😐

	40-01	☆)Menu)Diagnose)Personvogne)VOLKSWAGEN)ID.3 (20>] (E11))electric)Type 2 EBJA (70-110 kW) [/20>])		\downarrow
S ^O Manu	uel identifikation	VIN: WWWZZZEIZLP		
Auto-	-diagnose	Auto-diagnose	×	
E Kort		Download the Microsoft Authenticator using the download	VCI forbindelse: SMART	
O Teknis	ske data og tjek	Global system scan Handling ap of your choice.		
Passth	hru	Sørg any of the methods below to continue with enrollin	ie af	
(R) Kunde	lestyring	TG53s C Scan the QR code		
Eộ iSupp	port		San a Anders	
Canal Løste	fejl			
		Mileage and VIN check		
		Diagnose efter system		
		2 0001 Elektrisk motor styreenhed		
		O003 ABS Still having trouble?		
		🛃 0006 Sædejustering, passagersi Log ind :	myTEXA	
		* 0008 Air condition enhed 💿		
		2 0009 Kontrolpanel		
		2 0013 Afstandskontrol		
29/03/	/2023 13:05		© copyright and database right 20	016-2023

In future, the procedure below must be completed every time you log in to myTEXA on the TEXA diagnostic tool.

Authenticator App will now show a rolling code that changes every 30 seconds. Enter the code in TEXA and then log in.









ELEKTRO PARTNER

Page 9 of 9

ě

BULLETIN

SOLUTION CONTINUED:

It is now confirmed that the configuration has completed successfully. Pin code may be required. This pin code must be made by the workshop manager. See bulletin No. 9263 page 12.

	→ û ° 📀			IDC5 v.76.0.1 📯 🗙
Diagnose				VCI forbindelse: SMART
		io adas	Authenticator	(!) TPMS
Diagnose	Mileage and VIN check	Videokamera/radar kalibrering	ring af sprog	трмѕ
Ô	(+)	(?) WEB	Niveau 2 sikkerhedskonfiguration	
Programmering af transporttilstand	Special Functions	Løste fejl	Pinkode kan være påkrævet til kritiske handlinger såsom gateway-oplåsning eller aktivering af andre funktioner. På denne måde er det kun dig, der har adgang til disse funktioner. Under alle omstændigheder kan du aktivere det fra indstillingerne for IDCS	
Links og andre funkti	oner		Konfiguration fuldført med succes!	
(D)) (P)			Kontigurêr PiNkode	

You are now logged in.

TE		→ 값 ் ○						IDC5 v.76.	0.1 A X
	Diagnose	_						VCI forbindelse: s	<u></u> А
	Diagnose							(dame)	[]+ Logout
	Q			ିନ୍ଦୁ	<u>**</u> -+	©¢]			
	Diagnose	Mileage and VIN check		Elbiler	Udskiftning af batteri	Bremse Klods Udskiftning			
		• •	(?) WEB	PDF XML		/i\			
		Special Functions	Løste fejl	Report repository	EOBD Protokol	Test kørsel			
	Links og andre funkti	oner							
				TEXA					
See	e also bulle	etin No. 96	34.						

